


DEEP WELL JET PUMP REPAIR PARTS

(For Pricing Refer To Repair Parts Price List)

C62 & C62H SERIES SINGLE STAGE

HORSEPOWER	1/2
MODEL NUMBER	C6245
DESCRIPTION	PART NUMBER
Base Assembly	131236
Motor Support	131234
Motor Splash Cap	125706
Splash Cap Screw, 5/8" - 18	125707
Impeller, Brass	131279
Impeller Nut	131285
Coupling	131735
Spring	130963
Spring Centering Washer	131736
Suction Clearance Ring	130957
Shaft	127324
Bearing-Base	130731
Gasket	130968
Cartridge Seal, Complete	131103
Control Valve, Complete	C981A
Drain Plug, 1/4" NPT	*
90° Connector, 1/4" x 1/4"	*
1/4" Tube x 8"	*
Hex Head Cap Screws, 3/8" x 2-1/2" (4)	*
Motor Lead Wire	125096
Set Screw, socket head, cone point, 3/8" x 1/2" (2)	*
Set screw, socket head, cup point, 3/8" x 5/16" (2)	*
Hex Head Cap Screw, 3/8" x 3/4" (4)	*
Motor 1 Phase (Flatted Shaft)	92F105A



2 STAGE

HORSEPOWER	1/2	3/4	1	1 1/2
MODEL NUMBER	C6265	C6267 C6267H	C6269 C6269H	C62615
DESCRIPTION	PART NUMBER	PART NUMBER	PART NUMBER	PART NUMBER
Base Assembly	131236	131236	131236	131236
Intermediate Stage Assembly	131239	131239	131239	131239
Motor Support	131234	131234	131234	131234
Motor Splash Cap	125706	125706	125706	125706
Splash Cap Screw, 5/8" - 18	125707	125707	125707	125707
Impeller, Brass (2)	131273	131277	131275	131276
Impeller, Brass "H" Series (2)		131276	131279	
†Impeller Nut	131285	131285	131285	131285
Coupling	131735	131735	131735	131735
Spring	130963	130963	130963	130963
Spring Centering Washer	131736	131736	131736	131736
Hub Clearance Ring	131282	131282	131282	131282
Shaft	127325	127325	127325	127325
Spacer, Brass	131281	131281	131281	131281
Suction Clearance Ring	130957	130957	130957	130957
Bearing-Base	130731	130731	130731	130731
Gasket	130968	130968	130968	130968
Cartridge Seal, Complete	131103	131103	131103	131103
Hex Hd. Cap Screws, 3/8" x 4-1/4" (4)	*	*	*	*
Motor Lead Wire	125096	125096	125096	125096
Control Valve, Complete	C981D	C981D	C981D	C981D
Control Valve, Complete "H" Series		C981G	C981G	
1/4" Tube x 8"	*	*	*	*
90° Connector, 1/4" x 1/4"	*	*	*	*
Drain Plug, 1/4" NPT	*	*	*	*
Set Screw, socket head, cone point, 3/8" x 1/2" (2)	*	*	*	*
Set screw, socket head, cup point, 3/8" x 5/16" (2)	*	*	*	*
Hex Head Cap Screw, 3/8" x 3/4" (4)	*	*	*	*
Motor 1 Phase (Flatted Shaft)	92F105A	92F107A	92F110A	92F115A
†Motor 3 Phase (Flatted Shaft)	92F305A	92F307A	92F310A	92F315A

†Requires 126943 Impeller Nut for 3 phase Motor.

*Standard Hardware Item